

## EPSON ?????? T0714 Yellow C13T07144011



?????????: ??? ?????????? ?????

????:

????????????? ?????????? ?????:

????? ??? ??: 14,20 €

??? ??????: 14,20 €

??? ?????? ??? ??: 11,45 €

??? ??: 2,75 €

AIABEZIMO!

[?????? ?? ?? ??????](#)

?????????????: [EPSON](#)

?????????

????? **yellow** ??? ?????? ????? ?? ?????????? ??????????.

????????? ?????????? ?????????? **340**

?????? ? ???? ?????????? ??????????:

- **EPSON Stylus**  
D78 - D92 - D120 - DX4000 - DX4400 - DX5000 Series - DX6000 - DX7000F - DX7400 Series - DX8400  
DX9400F Series - S20 - S21 - SX100 - SX105 - SX110 - SX115 - SX200 - SX205 - SX210 - SX215 - SX218 - SX400 - SX405 - SX410 -  
SX415 - SX510W - SX515W - SX600FW - 610FW
- **EPSON Stylus Office**  
B40W - BX300F - BX310FN - BX600FW - BX610FW

?????? ????????

??? ?????????? ?????? ?????? ??? ?? ??????.

